

REPRODUCTION DOOR PANELS

CLIP INSTALLATION INSTRUCTIONS:

1. Place panel, vinyl side down, on a clean, smooth, hard surface.
2. Using a 1/16" flathead screwdriver, gently and slowly separate the two layers of board at each clip location, using a side to side slicing action, the two layers of board to form a pocket where the clip is to be inserted. (Illustration A). The separated area should be fan shaped, approximately 1/2" deep and 1" wide. (Illustration B)

HELPFUL HINT:

Bend the 1/16" screwdriver tip at a 30 degree angle for easier insertion.

CAUTION:

1) Do not separate the boards within 1/4" of the edge of the panel or damage to the panel may result.

2) Do not gouge or tear the board surface between the layers. If loosened material becomes wedged between the layers it could create a noticeable bulge on the front of the door panel.

NOTE:

You may notice a slight raising on the front side of the panel once the clips are in place. This is normal.

IF YOU HAVE POWER WINDOWS - All door panels front and rear have power knockouts on the back side of the board. In the event a power style door panel is required, simply trim with a razor blade and remove the knockout area.

For technical assistance contact our office directly at (315) 331-4444

